




CONVERT-2 & MONITOR ST




ANY DIGITAL DEVICES OR INTERFACES FOR MONITORING



OPTICAL CABLE

OR




USB CABLE

COMPUTER



INPUTS 1-4 CAN BE USED FOR ANY OF YOUR SOURCES, BUT ONE OF THEM MUST BE DESIGNATED FOR THE OUTPUT OF THE CONVERT-2



EXTERNAL TB REMOTE (SOLD SEPARATELY)



CUE MIX FEED, OR ANY AUXILIARY MONITORING SOURCE



TB MIC OUTPUT



TO HEADPHONE DISTRIBUTION SYSTEM